

# CARSON®

## LEDSight Pro™

### LED Flashlight



# SL-55


Congratulations on selecting your new LED Sight Pro! In order to achieve optimum performance, please follow instructions for proper use and care.

#### PRODUCT SPECIFICATION:


Illumination:	9 White UV LEDs
Batteries:	3 AAA (not included)
Weight:	0.15 lbs
Dimensions:	1.2" x 1.2" x 3.8"
Accessory:	Carabiner Clip

#### INSTALLING BATTERIES:

1. Twist off top of Flashlight (in a counterclockwise motion).



2. Pull out battery holder to insert 3 new AAA batteries in correct polarity.
3. Return battery holder to flashlight and replace top of flashlight (in a clockwise motion).




#### WARNING:

Use only alkaline batteries. Mixing old and new, different brands or types within brands may cause batteries to leak, overheat or explode. Keep away from fire or excessive heat. Inspect batteries for corrosion or leakage. Insert in direction indicated. Rechargeable batteries not recommended.

#### USING FLASHLIGHT: 2 BRIGHTNESS LEVELS

1. For brightest setting, press rubber end once.
2. For low light, press rubber end again.
3. Pressing a third time will turn Flashlight off.



4. To charge Glow-in-the-Dark Rubber Grip, place in direct light for 5-10 minutes.



#### Customer Service:

If you experience any difficulties please contact us and we will be happy to help you.



Email: [info@carson.com](mailto:info@carson.com)



Email: [uksupport@carson.com](mailto:uksupport@carson.com)



Email: [eusupport@carson.com](mailto:eusupport@carson.com)

For warranty information, visit [www.carson.com/warrant](http://www.carson.com/warrant)

**[www.carson.com](http://www.carson.com)**

Carson Optical 2070 5th Avenue,  
Ronkonkoma, NY 11779  
Tel: 631-963-5000